

## **How to install the front baffle, solvent box and ITM02 Maintenance Kit of Domino AX150 inkjet printer?**

Let's install the front baffle first,  
First install the left side and put it in:




Then, the baffle installation is completed:



Then we install the solvent tank,  
Install the air control pipe here, be sure to install it in place and insert it with force:



Then clip it in. There are two pillars corresponding to two holes:



Then we insert it in, and we must firmly plug it in, because if the two holes and sealing rings are not firmly inserted, air will leak:



Screw in black screws:







Then remove the Yellow plug on the outside of itm02 Maintenance Kit:



Then these O-rings are here:



Here's the chip:



When installing the Maintenance Kit, the two must be in place, otherwise ink will leak:



Installation complete:

