


How to remove the crystal of the Metronic Rottweil inkjet printer?

Remove the screw with a cross screwdriver:



Then, remove the other three screws:




This is a nozzle for 55,
The removal method is the same:



The crystal can then be pushed up from below:



This is the crystal:



The spray gun can then be replaced and the crystal reloaded.