


How to disassemble the screen of Imaje 9232/9410/ 9450 inkjet printer?


If we're going to take it down, we're going to have to take the four screws off first:



Then take off the front and loosen it:



Push the screen from behind and it can be taken off:



That is to say, if we want to remove this, the front panel needs to be removed, otherwise we can't push it from the back.