


## How to remove the nozzle of the Metronic Rottweil inkjet printer?

The wrench is 2.5,  
Remove the four screws:



Then, unplug the nozzle:

