


How to remove the jet gun of the Rotweil inkjet printer?

Remove the two fixing screws:



Remove the side fixing screw, 1.5:



There's another one on this side:



Then you can take it off:

